

# PRESS STOP VALVE

## Instruction Manual

### DOUBLE-O-RING TECHNOLOGY



### PRESS CONNECTION INSTALLATION INSTRUCTIONS FOR COPPER PIPE ONLY

*\*Make sure copper pipe is deburred and free of gouges*

1. Check seal for correct fit. Do not use oils or lubricants.
2. Mark proper insertion depth. Improper insertion depth may result in improper seal.
3. While turning slightly, slide press end onto tubing to mark the depth. End of tubing must contact stop.
4. Open the tool jaw and place at right angle on the valve. Visually check insertion depth using mark on tubing.
5. Start pressing process and hold down until tool jaw has engaged the press end. Only press outer ring.
6. After pressing, the jaw can be opened again.

Note:



**Outer Seal  
PRESS HERE**

**Inner Seal  
DO NOT PRESS**